

Calibration instructions for the PROFORM® wireless vehicle scale, part no. 67647.



Legend:

FL = Front Left

FR = Front Right

RL = Rear Left

RR = Rear Right



PLEASE NOTE: A 550 lb (250 kg) weight is required. Using any other weight can lead to permanent damage to the scale.

Procedure:

1. Turn ON the four weighing pads.
2. Make sure the switch on the battery pack is in the ON position, and then turn ON the LCD display.
3. With the **TARE** and **Kg/lb** buttons both being pressed, power on the LCD display by pressing the **ON/OFF** button until "0000" appears at the upper left position of the LCD display. Release all buttons once this is achieved.
4. Put 550 lbs. on the FL pad, wait 10 seconds for it to stabilize.
5. Slowly press and hold the **Kg/lb** button, then slowly press and release the **TARE** button multiple times until "15" appears in the upper right corner location. Release the **Kg/lb** button, and "15" will change to "0000" then show "550". This means the FL pad recorded the 550 pounds, and calibration of the FL pad is complete.
6. Put 550 lbs. on the FR pad, wait 10 seconds for it to stabilize.
7. Repeat step 5 until "25" appears in the upper right corner location. This means the FR pad recorded the 550 pounds, and calibration of the FR pad is complete.
8. Put 550 lbs. on the RL pad, wait 10 seconds for it to stabilize.
9. Repeat step 5 until "35" appears in the upper right corner location. This means the RL pad recorded the 550 pounds, and calibration of the RL pad is complete.
10. Put 550 lbs. on the RR pad, wait 10 seconds for it to stabilize.
11. Repeat step 5 until "45" appears in the upper right corner location. This means the RR pad recorded the 550 pounds, and calibration of the RR pad is complete.
12. Remove weights from pad, and off the LCD display by pressing the **ON/OFF** button.
13. Turn ON the LCD display again, and check each pad to ensure it weighs a known weight correctly (i.e. get on the scale and weigh yourself).

For additional Tech Support, call (586)774-2500 or email tech@proformparts.com

©2015 Specialty Auto Parts U.S.A., Inc. All rights reserved.