



Civic/Integra 01-06 (EP3/DC5)

## Engine Torque Damper

Tools needed: Ratchet with extension and 14 & 17mm sockets, 6mm allen key, 17mm spanner, Adjustable spanner

- Remove your right hand side suspension strut nuts and fit the bracket like so. If you have a Tegiwa or similar front strut brace, you do not need to use this bracket as there is a hole for an ETD already in the bracket.



- Remove the 17mm nut nearest the front of the car on the right hand side engine mount, then place the other ETD bracket onto the studs. Refit the original nut and fit the supplied nut onto the rear bolt.



# TEGIWA

I M P O R T S

- Mount your damper between the two brackets loosely, check the length and adjust if necessary. The dampers have a spring washer, this may need to be removed due to factory tolerances. Tighten the damper locknuts and the allen bolts.



If you have any questions about this or any of our other products please email us on [info@tegiwainports.com](mailto:info@tegiwainports.com) and we will be happy to help.