



Rear lower tie

Tools needed: Ratchet with extension and 13 & 14mm sockets, 5mm allen key

- Raise and support the rear of the car with axle stands on the chassis.
- Remove the innermost lower suspension arm bolts and put the lower tie brackets on, reuse these bolts. It is easier if you do this one side at a time rather than undo both bolts before putting one side back on. Screw the bolts in but leave them loose at this stage
- Fit the tie bar in between the mounts with the allen bolts going down from the top.
- Tighten all bolts and apply the sticker. Your low tie bar should now look like this (EP3 with TEGIWA lower arms shown)



If you have any questions about this or any of our other products please email us on info@tegiwaimports.com and we will be happy to help.