



Honda S2000 99-09 Master Cylinder Brace Fitting Guide

Tools needed

Ratchet with 10mm socket and extension
10mm spanner
13mm spanner
5mm Allen Key

Fitting Guide

Step 1

Remove the two 10mm bolts holding the black control module onto the inner wing and attach the L shaped bracket as shown with the longer bolts supplied.



TEGIWA

I M P O R T S

Step 2

Bolt the other long C shaped bracket to the first bracket, and then to the suspension turret with the supplied bolts, washer and nut like so;





Step 3

Screw the stud into the welded on nut with a 5mm allen key, then when it's through put the red washer over the end and support it. Tighten it up so it is sitting snugly against the end of the master cylinder. Then use the 13mm nut and tighten it against the blue bracket to secure it in place.



Finally make sure the red washer is pushed up against the master cylinder and can't rattle around.

If you have any questions about this or any of our other products please email us on info@tegiwaimports.com and we will be happy to help.